

POS NO.	SPARE PART DESCRIPTION	PCS	ITEM NO.
	Speaker G-8270		2837700
1	Speaker Visaton FX13 No. 4570	4	5574590
2	Speaker rosette	4	5595640
3	Speaker mounting plate	4	5595630
4	Speaker cover	4	5595680
5	Screw M5x16 ISO-10642	16	9903162
6	Screw 4x35	16	9903284
7*	Key hex PN-ISO 2936-2	4	9919050
8	Expansion bolt 6x30	16	9903285
9	Nut M5 -ISO 4032	16	9901036
10	Spacer sleeve	16	5574580
11	Screw M4x6 ISO4027	12	9903212